

URh 3600

Fully integrated under counter
refrigerator
○ Pure

LIEBHERR

Fully Integrated



Fully Integrated

URh 3600

Fully integrated under counter refrigerator
○ Pure

↑
82-88
↓



Touch Control

LED

Soft System

Super Cool

Type	Fixed door / Under-worktop appliance for integrated use
Energy consumption (kWh/yr) / Star rating	90 / 5.0
Total volume	127 l ¹
Climate rating	SN-T (+10 °C to +43 °C)
Frequency / voltage	50/60 Hz / 220-240 V~
Connection Rating	2.0 A
Aperture dimensions in cm (h / w / d)	82-88 / 60 / min. 56
Controls	
Type of Control	TouchControl, touch electronic Digital temperature display
Door alarm	visual and acoustic
Alarm in case of malfunction	visual and acoustic
Fridge compartment	
Door interior	Plastic door shelves with bottle holder, egg tray
Interior light	LED lighting
Fruit and vegetable bins	1 Half fruit and vegetable compartment, 1 Multi-purpose box
Features	
Door hinges	Reversible door hinging, right
Replaceable door seal	yes
EAN-Nr.	9005382259610

¹ In accordance with Regulation EU 2019/2016 we indicate the total volume to the nearest integer (rounded off) and the volume of the frozen compartments and refrigeration compartments to one place after the decimal point.

Features



Fruit and Vegetable box

The Fruit and Vegetable box offers a convenient and organized solution for your fresh produce. With its compact yet spacious design, it provides ample room for fruits and vegetables. The transparent construction allows for easy visibility and quick access, while the easy-to-clean surface ensures hassle-free maintenance. Perfect for those who value freshness and organization in their refrigerator.



TouchControl

A gentle finger tap and you set your Liebherr to 3, 5, 7 or 9° with TouchControl. So simple – and efficient, as the sleek button is integrated into the interior, creating more space for all your fresh goods.



LED light inside

The LED side lighting illuminates the interior from the side – providing a good overview of your food. Another highlight: the LEDs are positioned in front of the glass shelves so that even a full refrigerator is well lit.



GlassLine shelves

If you store a carafe or tall container in the refrigerator, you don't want to have to remove an entire glass shelf. And why should you? Because there are separable glass shelves. Simply slide the front half of the glass shelf under the back half. This allows you to place higher containers at the front and still have enough space for other food.



Universalbox


The Universalbox makes the perfect home for small food items: Tubes or small cans, for example, can be stored safely and clearly in the bottom drawer. The transparent box not only offers plenty of space but is also easily accessible. And the robust surface is particularly easy to clean – saving time and effort.



Half Door Racks

Enjoy even more flexibility and convenience when storing your food: The two half door racks can be moved and adjusted in height as required. This means that e.g. cans or small screw-top jars find a safe and easily accessible place. Plus, the stainless steel look trim gives the racks an elegant look.

Technical drawing



Maximum weight of furniture door:
Fridge compartment: 10 kg

Products and their details are staged for advertising purposes. Whilst every effort is made to ensure all specifications and information in this flyer are accurate, Liebherr reserves the right to make changes without notification. Where actual appliance measurements, specifications, and ratings are crucial, we recommend that the actual appliance installation instructions that accompany each appliance be checked. Liebherr will not be liable for any damage. (15.04.2025)

